McKenzie Occasional Table

GAC = Glazed Antique Cherry finish

CAF = Caffè finish

Assembly Instructions
Model #

3497GACb 3497CAFb McKenzie Accent Table



3498GACb 3498CAFb McKenzie Side Table



Thank you for allowing us to help you furnish your home. We are certain you will be delighted with your new furniture for many years to come.

IMPORTANT NOTES:

- For normal household use only. Not recommended for commercial use.
- Do not climb, sit, or stand on this piece of furniture.
- Unload items before you move this unit.
- Do not overload the shelves.

WARNING

Drilling, sawing, sanding or machining wood products can expose you to wood dust, a substance known to the state of California to cause cancer. Avoid inhaling wood dust or use a dust mask or other safeguards for personal protection.

For more information go to: www.p65warnings.ca.gov/wood

This product can expose you to chemicals, including formaldehyde, which are known to the State of California to cause cancer. For more information go to: www.p65warnings.ca.gov/furniture

DESIGN SUBJECT TO CHANGE WITHOUT NOTICE.

CUSTOMER SERVICE

If you ever have questions about your furniture, please do not hesitate to contact us. In the unlikely event you need a replacement part; we can make those parts available through an authorized Whittier Wood Furniture dealer. If you cannot order replacement parts through your dealer, please contact our customer service department.

Hours: Our friendly customer service staff can be reached:Monday-Friday 8:00 a.m. to 5:00 p.m. (Pacific Time).You may leave a message 24 hours a day, seven days a week.

Customer Service: 800-653-3336 • Outside the U.S.: 541-687-0213

Fax: 541-687-2060 • Email: info@whittierwood.com



VN	06/20
Production Code:	

3497GACb 3497CAFb McKenzie Accent Table 3498GACb 3498CAFb McKenzie Side Table

Parts List

Please identify the parts and check that quantities received match those on this list. If you need to replace a part, refer to the following letter and part name.

Part	Description		Quantity
		101:02	
Aa	Top Assembly		1
В	Leg	0	4
С	Shelf Assembly		1
D	#8 x 1-1/4" Pan Head Screw	(*)	30 (22 inserted)
Е	5/16" Flat Washer		4
F	3/8" x 2-1/2" Hex Bolt		4
Н	3/8" x 1" Insert Nut (inserted)		4
K	Wood Dowel (inserted)		4
L	1/4" x 20mm Insert Nut (inserted)		4
M	#8 x 1-3/8" Lo-Profile Screw (inserted)	accecececa	4
N	#8 Washer (inserted)		6
0	Slotted Leveler (installed)		4
P	Leveler Adjustment Key (attached to Owners Manual)		1


3497 shown in the illustrations.

3497GACb 3497CAFb McKenzie Accent Table 3498GACb 3498CAFb McKenzie Side Table


Assembly Instructions

Tools Required: Phillips Screwdriver, 9/16" or Adjustable Wrench Tool Provided: Leveler Adjustment Key in the Zip bag taped to the Owner's Manual and Safety Guide.

1. Turn the Top Assembly (Aa) upside-down on a clean, protected surface. Position the Legs (B) in the corners so the Insert Nuts (H) face in. LOOSELY attach with four 5/16" Flat Washers (E) and four 3/8" x 2-1/2" Hex Bolts (F) (the legs should be wobbly). See Figures 1 and 1a.




2. Turn the Shelf Assembly (C) upside-down and place the dowels into the dowel holes in the Legs. Tighten the Hex Bolts on the Legs. See Figure 2.



3497GACb 3497CAFb McKenzie Accent Table 3498GACb 3498CAFb McKenzie Side Table

Assembly Instructions

3. Using the pocket holes as guides, secure the Shelf (C) to the Legs (B) with eight #8 x 1-1/4" Pan Head Screws (D). See Figures 3 and 3a.



4. Turn the table upright and place the table at its final destination. Use the Leveler Adjustment Key (P), found in the Zip bag taped to the Owner's Manual and Safety Guide to rotate the Slotted Levelers (O) on the bottoms of the legs until the table is level. See Figures 4 and 4a.

